

Режимы подключения DVR Optimus

Модель	Режим работы	Аналоговый режим		Сетевой режим				
		960Н	D1	1080P	960P	720P	960Н	D1
 DVR-2008E	1	8						
	2		8					
	3		8					
	4							
	5		2	1		1		
	6							9
	7						8	
	8					4		
	9			2				
	10			1				
	11					1		7
	12				1	1		2